Q

Q ROUTE- 'Q' is the designator assigned to published RNAV routes used by the United States.

QFE- The atmospheric pressure at aerodrome elevation (or at runway threshold).

QNE- The barometric pressure used for the standard altimeter setting (29.92 inches Hg.).

QNH– The barometric pressure as reported by a particular station.

QUADRANT- A quarter part of a circle, centered on a NAVAID, oriented clockwise from magnetic north as follows: NE quadrant 000-089, SE quadrant 090-179, SW quadrant 180-269, NW quadrant 270-359.

**QUEUING-**

(See STAGING/QUEUING.)

QUICK LOOK- A feature of the EAS and STARS which provides the controller the capability to display full data blocks of tracked aircraft from other control positions.

Pilot/Controller Glossary